

ARTECH

STEPLINE – INSTALLATION GUIDELINES

Step No. 1

The surface or groove, to which Stepline will be applied, should be clean, dry and free from dust and loose particles. The specification for Stepline should be 1.0mm less than the width of the groove, and should project 0.5mm – 1.0mm proud of the surrounding surface. Stepline may be supplied predrilled for screw fixing with adhesive or undrilled for adhesive fixing only.

Step No. 2

The predrilled Stepline insert should be offered up without adhesive applied onto the prepared surface and the holes marked out. Remove the Stepline insert and drill the prepared surface using a No. 6 drill bit. When drilling into concrete, a red plug should be used. Remove all dust and loose particles.

Step No. 3

Apply the selected adhesive to the prepared surface. Follow the instructions on the adhesive container.

Step No. 4

Place the Stepline insert into the adhesive and apply pressure to allow full adhesive transfer and to remove any air pockets.

Step No.5

Using No. 6 screws fix the Stepline insert into the adhesive and use the caps provided to cover the screw head.

NB

Always allow sufficient time for the adhesive to fully cure before allowing foot traffic.

For further information, contact the Technical Helpdesk

Sheet Ref: S/L Inst. 01
Data Sheet: NOV 2007