

STEPLINE CARBORUNDUM INSTALLATION GUIDELINES

Stepline Carborundum can be installed into preformed channels or the material can be routed out to create the channel for the insert to be installed into.

For both internal and external installation we recommend PROBOND® B490 Adhesive. Always allow sufficient time for the adhesive to fully cure before any allowing foot traffic.

INSTALLATION INSTRUCTIONS:

1. The surface or groove, to which Stepline Carborundum will be applied, should be clean, dry and free from dust and loose particles and any contaminants.
2. Apply PROBOND® B490 Adhesive to the underside of the Stepline in 5mm wide beads. For profiles up to 60mm wide a bead of adhesive should be applied to each edge of the profile and for wider profiles apply additional beads.
3. Place the Stepline insert into the adhesive and apply pressure to ensure full adhesive transfer and to remove any air pockets.

For further information, contact the Technical Helpdesk

Sheet Ref: SLC/I Inst. 02
Data Sheet: Aug 2019