

STEPLINE MODENA INSTALLATION GUIDELINES

Stepline Modena can be installed into preformed channels or the material can be routed out to create the channel for the insert to be installed into.

For both internal and external installation we recommend PROBOND® B490 Adhesive. Always allow sufficient time for the adhesive to fully cure before any allowing foot traffic.

INSTALLATION INSTRUCTIONS:

1. The surface or groove, to which Stepline Modena will be applied, should be clean, dry and free from dust and loose particles and any contaminants.
2. Apply PROBOND® B490 Adhesive into the created channel.
3. Place the Stepline insert into the adhesive and apply pressure to ensure full adhesive transfer and to remove any air pockets.

Sheet Ref: SLM/1 Inst. 02
Data Sheet: Aug 2019