

ARTECH

STEPLINE - MAINTENANCE

Preventative Maintenance

Regular maintenance prevents build up of dirt and grease which will reduce the anti-slip properties of these inserts and lessen the visual impact.

Daily Cleaning

Sweep the area daily and spot clean any obvious marks or grease spots with a mild detergent and warm water. Very stubborn stains can be removed by gently using fine wire wool. Dry thoroughly after.

Weekly Cleaning

Sweep the area then clean the entire area with a mild detergent and warm water. A green maintenance pad may be used. Change the water during this process to eliminate the spread of grim. After this process is complete, the entire area should be thoroughly dried with a clean cloth.

NB

Do not use polish or floor sealers on the Stepline inserts as this will adversely affect the slip resistant properties.

Aggressive detergents could affect the colour of the insert.

The above will vary due to usage.

Sheet Ref: S/L Prev. 01
Data Sheet: NOV 2007